

All Occasions Party Rentals, Inc.

From Moments to Milestones ... We Rent for Your Event!

1936 Windsor Road, Kelowna BC V1Y 4R5

Phone: 250-763-8687 Fax: 250-763-9945

On the web: www.alloccasionspartyrent.com

Email: alloccasions@telus.net

Paradise Candles

1. Never store or transport paradise candles while they are loaded with wax refills. In warm temperatures the constant spring pressure of the inner cartridge can cause the wax refill to deform to the point where proper spring feeding of the refill is impossible.
2. When lighting the wax refill it is important to hold the flame of the match or lighter at the base of the wick near the wax until the wax starts to melt. This helps the wax to start flowing up the wick and will make the candles easier to keep burning.
3. To re-light a previously used wax refill, break off a little candle at the top to expose fresh wick to make lighting easier.
4. Direct down draft on the paradise candle can cause the wax to drip and scorching of the outer shell. Please keep out of the way of drafts.
5. If wax gets on the outer shell, do not scrape off. Rinse under hot water till the wax melts away and then dry with a soft cloth.