

All Occasions Party Rentals, Inc.

From Moments to Milestones ...We Rent for Your Event!

1936 Windsor Road, Kelowna BC V1Y 4R5

Phone: 250-763-8687 Fax: 250-763-9945

On the web: www.alloccasionspartyrent.com

Email: alloccasions@telus.net

Fabric Steamer

1. Place the rod set into the slot that holds it in place on the base of the steamer.
2. Remove the cap from the blue water bottle. Fill the bottle with regular tap water; replace the cap and turn the bottle upside down to fit it into the body of the steamer.
3. Always make sure there is water in the bottle. **DO NOT ALLOW THE STEAMER TO RUN DRY.**
4. Plug the steamer cord into the wall and turn the unit on, wait for about sixty seconds for the steam to start.
5. After use, turn the steamer off and unplug it. Empty the water bottle before transporting. Allow steamer to cool before storing or transporting.