

# ALL OCCASIONS

PARTY & EVENT RENTALS

## FABRIC STEAMER INSTRUCTIONS

- Place the rod set into the slot that holds it in place on the base of the steamer.
- Remove the cap from the blue water bottle. Fill the bottle with regular tap water; replace the cap and turn the bottle upside down to fit it into the body of the steamer.
- Always make sure there is water in the bottle. DO NOT ALLOW THE STEAMER TO RUN DRY.
- Plug the steamer cord into the wall and turn the unit on, wait for about sixty seconds for the steam to start.
- After use, turn the steamer off and unplug it. Empty the water bottle before transporting. Allow steamer to cool before storing or transporting.